



C901a - P91 Central junction box (CJB)

C901a




C901b - P91 Central junction box (CJB)


## C901b



before 95, RS  
Cosworth



before 95, RS  
Cosworth



---


## C901c - P91 Central junction box (CJB)

---

## C901c


RHD

before 95, RS  
Cosworth



LHD


before 95, RS  
Cosworth



## C902a - P91 Central junction box (CJB)

RHD


before 95, RS  
Cosworth




## C902a

LHD

before 95, RS  
Cosworth




## C902b - P91 Central junction box (CJB)




---

## C902c - P91 Central junction box (CJB)

---




---

## C902d - P91 Central junction box (CJB)


---

## C902d

RHD

before 95, RS  
Cosworth


F04029.01



LHD

before 95, RS  
Cosworth

F04029.01




## C903a - P91 Central junction box (CJB)

RHD

before 95

F10002.01




C903a

LHD

before 95


F10002.01



RHD

RS Cosworth


F10002.01



LHD

RS Cosworth

F10002.01




## C903b - P91 Central junction box (CJB)

## C903b


RHD

before 95




LHD

before 95




RHD

RS Cosworth



LHD

RS Cosworth




## C903c - P91 Central junction box (CJB)

## C903c


RHD

before 95




LHD

before 95




RHD

RS Cosworth



LHD

RS Cosworth




## C903d - P91 Central junction box (CJB)


## C903d




before 95




before 95



RS Cosworth



RS Cosworth



---


## C903e - P91 Central junction box (CJB)

---






before 95




## C903e




before 95



RS Cosworth



RS Cosworth



---

## C904a - P91 Central junction box (CJB)


---

## C904a

RHD

before 95


F05049



LHD

before 95


F05049



RHD

RS Cosworth


F05049



LHD

RS Cosworth


F05049



## C904b - P91 Central junction box (CJB)

RHD


before 95



**C904b**


LHD

before 95




RHD

RS Cosworth



LHD


RS Cosworth




## C904c - P91 Central junction box (CJB)

## C904c


RHD  
before 95




LHD  
before 95



RHD  
RS Cosworth



LHD  
RS Cosworth



---

## C904d - P91 Central junction box (CJB)

---





before 95

## **C904d**





before 95



RS Cosworth



RS Cosworth



---


## **C904e - P91 Central junction box (CJB)**

---

RHD

before 95

F05050




**C904e**

LHD

before 95


F05050



RHD

RS Cosworth


F05050



LHD

RS Cosworth

F05050



---


## C905a - P91 Central junction box (CJB)

---

## C905a


RHD

before 95, RS  
Cosworth



LHD

before 95, RS  
Cosworth




## C905b - P91 Central junction box (CJB)

## C905b


RHD

before 95, RS  
Cosworth



LHD

before 95, RS  
Cosworth




## C905c - P91 Central junction box (CJB)

## C905c


RHD

before 95, RS  
Cosworth



LHD


before 95, RS  
Cosworth



## C905d - P91 Central junction box (CJB)

RHD


before 95, RS  
Cosworth



## C905d

LHD

before 95, RS  
Cosworth




## C907 - P91 Central junction box (CJB)



## **C907**

before 95, RS  
Cosworth

F05052



---


## **C908 - P91 Central junction box (CJB)**

---

## **C908**

before 95, RS  
Cosworth

F04025




## C909a - P91 Central junction box (CJB)

---

### C909a

before 95, RS  
Cosworth




---

## C909b - P91 Central junction box (CJB)

---

## C909b


before 95, RS  
Cosworth



---

**C910 - P91 Central junction box (CJB)**


---




---

## C911 - P91 Central junction box (CJB)

---




---


## C912 - P91 Central junction box (CJB)

---

## **C912**

before 95, RS  
Cosworth

F04029



---


## **C915 - A15 EEC IV module**

---

## C915 (Grey)



F55001




---

## C920a - A70 Instrument cluster

---

### C920a

before 95 1/2



(2) 61-B (BU)  
61-A (BU)

(9) 31B-92 (BN/WH)  
31B-93 (BN/WH)

(13) 58-9K (GY/YE)  
58-10A (GY)

---

## C920b - A70 Instrument cluster


---



## **C920b**

before 95 1/2

F06022.01



---

**C1152 - K11 Intermittent wiper relay, front**

---

## **C1152**




---

## **C1153 - K1 Rear window heater relay**

---

## **C1153**




---

## **C1154 - K18 ABS Main relay**

---

## **C1154**

F05051




---

### **C1155 - K25 ABS Pump relay**

---

## **C1155**

F04056








## C1156


before 95

F04056




as of 95

F04057



before 95

F05051




---

## C1157 - K9 Intermittent wiper relay, rear


---

### **C1157**

before 95



as of 95



K9

Higher option con-  
tent

P25

Lower option con-  
tent

---


## C1158 - K13 Power hold relay

---

## **C1158**


before 95

F04056



as of 95

F04057




---

**C1159 - K4 Fuel pump relay**

---

## **C1159**

F04057




---

## **C1160 - K84 Engine run relay**

---

## **C1160**

F04057






## C1161 - K32 A/C Wide Open Throttle (WOT) relay

---

### **C1161**

F04057



---


## C1162 - K81 Cold advance relay

---

## **C1162**

before 95

F04057




---

**C1163 - K78 Dim-dip relay I**

---

## C1163



K78

Scandinavian

K80



P24


---

**C1166 - K95 Fuel pump relay 4x4**

---

## **C1166**

F04056




---

### **C1167 - K96 Delayed interior light relay**

---

## **C1167**


F05051



## C1169 - P22 Busbar for rear fog lamp

---

### C1169




---

## C1170 - K79 Dim-dip relay II

---

## C1170

F04057



K79

RHD

K5

Scandinavian


---

## C1171 - A82 Front fog lamp module

---

## C1171

F04056



A82

NL

P23

~~NL~~


---

## C1172 - K34 Headlamp cleaning relay

---

### C1172

F05051




---

## C1173 - K36 Dip beam relay

---

## **C1173**

F04057




---

### **C1174 - K94 Start inhibit relay**

---

## **C1174**


F04056





**C1175 - K26 Front fog lamp relay**

---




---

**C1176 - K41 Ignition relay**

---

## **C1176**

F04056



---



**C1179 - K70 Pre-glow relay Diesel**

---

## **C1179**

before 95

as of 95




---

## **C1182 - K45 Engine cooling fan relay**

---

## **C1182** (Dark green)

F08025




---

## **C1183 - K59 A/C Relay**

---

## **C1183** (Green)


F08036



## C1184 - K3 Heated front windscreen relay

---

### C1184




---

## C1192 - K101 Power roof relay III

---

### C1192 (Green)

Cabriolet



---


## C1193 - K102 Power roof relay IV

---

## **C1193** (Yellow)

Cabriolet

F05009



---


## **C1194 - K99 Power roof relay I**

---

### **C1194**


Cabriolet before 95

F05010



Cabriolet as of 95

F05010




---

## **C1195 - K100 Power roof relay II**

---

## **C1195**




---

## **C1197 - K103 Power antenna relay**

---

## **C1197**




---

## **C1198 - K85 Assembly alarm relay - cabriolet**

---

## **C1198**




---

## **C1199 - K86 Power window adjust relay**

---

## **C1199**



---


## **C1205 - E1 LH Headlamp**

---




## **C1205** (White)


Lower option content,  
before 95 1/2



Higher option content,  
before 95 1/2



as of 95 1/2



---

## **C1206 - E7 RH Headlamp**

---

RHD



## C1206

LHD

Lower option content,  
before 95 1/2

(White)

Lower option content,  
before 95 1/2





RHD

LHD

Higher option content,  
before 95 1/2

(White)

Higher option content,  
before 95 1/2





RHD

LHD

as of 95 1/2

(White)

as of 95 1/2




## C1214 - E10 Rear lamp assembly right

## C1214


RHD

Wagon, notchback Cabriolet, RS  
Cosworth




LHD

Wagon, notchback Cabriolet, RS  
Cosworth




RHD

Hatchback




LHD

Hatchback




RHD

Van



LHD

Van




## C1215

RHD

Wagon, notchback

Cabriolet, RS  
Cosworth

F07013




LHD

Wagon, notchback

Cabriolet, RS  
Cosworth


F07013



RHD

Hatchback


F05024



LHD

Hatchback


F05024



RHD

Van


F07013



LHD

Van

F07013




---

## C1224a - E87 Cargo space lamp

---

### **C1224a**

Van




---

## C1224b - E87 Cargo space lamp

---

## **C1224b**

Van




---

### **C1226a - E19 Interior lamp rear**

---

## **C1226a**

Wagon



C1226b - E19 Interior lamp rear

---

**C1226b**

Wagon





---

**C1292**

---

**C1292**




---

**C1300 - N148 Contact plate tailgate**

---

F03060

## **C1300**



Wagon, hatchback


---

## **C1311 - A31 Fuel tank unit**

---

## **C1311**


F05012




- (1) 31-67A (BN)  
31-67 (BN)  
31-37B (BN)
  - (2) 31B-55 (BN/GN)  
31-55 (BN)  
31B-55A (BN/GN)
  - (3) 54-15 (BK/RD)  
31-15 (BN)  
54-15B (BK/RD)
  - (4) 31-37 (BN)  
31-37C (BN)
  - (5) 31B-87 (BN/BK)  
31-17 (BN)  
31B-87A (BN/BK)
-



C1317 - B59 HEGO 1 sensor




C1318 - B60 HEGO 2 sensor



C1319 - B11 Vehicle speed sensor (VSS)

## **C1319**




---

## **C1328 - B22 Mass Air Flow (MAF) sensor**

---

## **C1328**




---

## **C1329 - B8 Throttle Position Sensor (TPS)**

---

## C1329





---

## C1331 - B2 Manifold Absolute Pressure (MAP) sensor

---

## **C1331**

F03013




---

## **C1342**


---

## **C1342**

F06007



F06008




---

## **C1343 - B41 Camshaft position sensor**

---

### **C1343**





---

## **C1344 - B19 Fuel sender**

---

### **C1344**




---

## **C1352 - N1 Brake fluid level switch**

---

## **C1352**






---

## **C1353 - N15 Stop lamp switch**

---

## **C1353**



---

## **C1357 - N169 Engine cooling fan temperature switch**

---

## **C1357**




---

## **C1358 - N202 A/C Cooling fan temperature switch**

---

## **C1358**



---



## **C1360 - N19 Reversing lamps switch**

---

manual transmission, MTX75

## **C1360**

manual transmission, B5




---

## **C1361 - N159 De-icing switch**

---

## **C1361**



---

## **C1362 - N160 A/C Pressure control switch**

---



## **C1362**




---

## **C1367 - N189 Power roof switch**

---

## **C1367**




---


## **C1377 - N61 Inertia switch**

---


**C1377**




**C1415 - A39 Clock**



**C1415**




**C1422 - N14 Heater blower switch**




---

**C1500 - N193 Power mirror adjust switch**

---




## C1502a - N10 Rear window heater switch

---

### **C1502a**

F04003



(2) 31-15 (BN) +31-15A (BN)  
31-15 (BN) as of 95


(3) 31-15A (BN)  
31-15A (BN) +31-15 (BN)

---

## C1502b - N10 Rear window heater switch

---

## **C1502b**




---

### **C1503a - N91 Windscreen heater switch**


---

## **C1503a**




C1503b - N91 Windscreen heater switch

C1503b




C1504 - N171 Heated seat switch, driver side

C1504



C1505 - N172 Heated seat switch, passenger side


## C1505





## C1506 - N13 Headlamp levelling switch



## C1506





## C1507 - N182 Power window switch, driver side front




---

## C1508 - N181 Power window switch, passenger side front

---




---


## C1514 - N14 Heater blower switch

---



## C1514

F08005




---

## C1519 - N150 Headlamp, turn lamp, horn, wiper switch

---

## C1519



(6) 30-7 (RD)  
30-7B (RD) as of 95

(10) 30-9 (RD)  
30-9B (RD)

(1) 56B-A (YE)  
56B-B (YE)


(3) 56A (WH)  
56A-A (WH) as of 95

---

## C1520 - N150 Headlamp, turn lamp, horn, wiper switch

---

## **C1520** (White)



---

**C1540 - N155 Tailgate/decklid release switch**

---

## **C1540**

before 95 1/2

as of 95 1/2




---

### **C1542a - N56 Front fog lamp switch**

---

## **C1542a**




---

### **C1542b - N56 Front fog lamp switch**

---

## C1542b




---

### C1544 - N5 Rear fog lamp switch

---

#### C1544 (White)



---


### C1555 - N155 Tailgate/decklid release switch

---

## **C1555**

RS Cosworth

F04042




---

### **C1556 - N204 Door lock switch, driver side**

---

## **C1556**


F04017



## C1558 - N205 Door lock switch, passenger side

---

### C1558




---

## C1560 - N166 Automatic transmission block switch

---

### C1560




---

## C1570 - N185 Power window inhibitor switch

---

## **C1570**



---

## **C1572**

---

### **C1572** (Black)




---

## **C1601 - A78 ESCP III Ignition module**

---



## **C1601**




---

## **C1602 - A6 ESC II Ignition module**

---

## **C1602**




---


### **C1603 - A6 ESC II Ignition module**

---

## **C1603**




## C1606




## C1609 - A36 Auxiliary warning module

## C1609



## C1610a - A77 Anti-theft/central locking module

## C1610a





---

### C1610b - A77 Anti-theft/central locking module

---

## **C1610b**



(1) 30-22E (RD/YE)  
30-22 (RD/YE)

(3) 15-1 (BK)  
15-3 (BK)

(2) 15 (BK)  
15-3A (BK)


---

**C1611 - A75 Electronic diesel control module (EDC)**

---

## C1611

F15005





(5) 9-20 (BU/GN)  
9-20 (BU/GN) +9-20A (BU/GN)

---

**C1629 - M3 Heater blower motor**

---

## **C1629**




---

**C1632 - A32 Additional fuel tank unit**

---



## **C1632**




---


### **C1635 - M46 Windscreen wiper motor**

---


## **C1635**



C1637 - M1 Headlamp alignment motor, left




C1638 - M4 Headlamp alignment motor, right



C1640 - M70 Throttle control motor

## **C1640**




---

## **C1648 - M11 ABS Hydraulic pump**


---

## **C1648**



C1649 - A8 ABS Hydraulic control unit



C1649





C1651

C1651

Cabriolet before 95




Cabriolet as of 95



C1916 - T3 DIS Ignition coil

## **C1916**

F03045




---

## **C1922 - P6 Octane adjust plug**

---


## **C1922**

2,0 IEFI




C1940 - D16 ABS Test connector

C1940




C1944

C1944



C1945 - N19 Reversing lamps switch

**C1945**



---


**C1946**

---

## C1946


1.4 I EFI

F12004




1.4 I EFI

F12001




2.0 I EFI

F12004




2.0 I EFI

F12001




RS Cosworth

F12004



RS Cosworth


F12001



## C1947




## C1947





## C1953

## C1953



## C1954

**C1954**





---

**C1962**

---

**C1962**




---

**C1963**

---

## C1963







## C1991 - D23 Diagnostic connector

## C1991



## C1992 - P21 Idle adjust plug

## **C1992**






---

## **C2000 - K92 Power window relay, driver side rear**

---

## **C2000**





---

## **C2001 - K90 Power window relay, driver side front**

---

## C2001




---

## C2002 - K89 Power window relay, passenger side front

---

## C2002




---

## C2003 - K91 Power window relay, passenger side rear

---


## C2003



## C2005

### C2005


Passenger side



## C2006

## C2006

Driver side rear




as of 95



## C2007

## C2007

Driver side




## C2008



## C2008



Passenger side rear





## C2009

## C2009

before 95





as of 95





## C2016

## C2016



## C2017

**C2017**





---

**C2030**

---

**C2030**



---

**C2033**

---


## C2033

RHD

before 95

Van

F08008




LHD

before 95

Van


F08008



RHD

before 95


F08027



LHD

before 95


F08027



RHD

as of 95


F06008



LHD

as of 95


F06008



RHD

as of 95


F06007




LHD

as of 95

F06007




**C2038** (Grey)




**C2041 - H9 Buzzer**

**C2041**




**C2100 - A11 Radio**

## C2100 (Yellow)




## C2101 - A11 Radio

## **C2101**




## **C2104**






## **C2164** (Yellow)



## **C2168**




---

**C2204**

---

## **C2204**




---

## **C2205 - D23 Diagnostic connector**

---

## **C2205**




## C2207 - N191 ABS Pressure switch

---

### **C2207**

RS Cosworth

F05022




---

## C2208 - A8 ABS Hydraulic control unit

---

## **C2208**

RS Cosworth




---

## **C2209 - B61 ABS Deceleration sensor**

---

## **C2209**

RS Cosworth




## C2218 - K18 ABS Main relay

---

**C2218** (Dark green)

RS Cosworth




---

## C2219 - K97 ABS Pump relay I

---

## **C2219** (Violet)

RS Cosworth




---

## **C2220 - K98 ABS Pump relay II**

---


## **C2220** (Violet)

RS Cosworth



C2221a - A76 Minor gauge cluster

---



---

C2221b - A76 Minor gauge cluster


---



## C2221b

RS Cosworth

F02006





---

## C2226

---

### C2226




---

## C2227 - K34 Headlamp cleaning relay

---

**C2227**



---

**C2243**

---

**C2243**




---

**C2244**

---

## **C2244**




---

### **C2245 - K93 Radiator fan relay**


---

## **C2245**

RS Cosworth




C2248



C2250 - K87 Power window relay I (global down)

## **C2250**




---

### **C2251 - K88 Power window relay II (global up)**

---


## **C2251**



## C2253 - B49 Exhaust gas recirculation (EGR) valve position sensor

---

### **C2253**




---

## C2255 - B2 Manifold Absolute Pressure (MAP) sensor

---

## **C2255**

F03013



---


### **C2256 - D19 Self-test input connector**

---

## **C2256**

RS Cosworth

F03015




## C2258 - A41 Illumination dimmer

---

### **C2258**

RS Cosworth

F06027



---

## C2263 - K59 A/C Relay

---



## **C2263** (Yellow)


RS Cosworth

F05009

31B-12 (BK/YE) +  
31B-12C (BN/WH)

31-23B (BN) +  
31-30E (BN)

54-16G (BK/WH)



31-23C (BN) +  
31-30E (BN)

---

## **C2264**

---


## **C2264**

F07016

33-AG6 (YE)

14-AG7 (VT/BU)

31-AG7 (BK)





31-AG6 (BK)

32-AG10 (WH/BU)

## C2265 - P13 Clock spring

---

### C2265



---


## C2268 - A29 Airbag module

---

## C2268


before 95 1/2

F26002



as of 95 1/2

F26002



---

## **C2269**




---

## **C2270 - K82 HEGO relay**

---

### **C2270** (Green)

RS Cosworth





---

## **C2271**

---

## **C2271**





---

## **C2272**

---

## **C2272**




---

## **C2278 - N170 Power window switch global up/down**

---

## **C2278**





---

## **C2281 - M67 Door lock motor, driver's side**

---

## **C2281**




---


## **C2283 - M22 LH Rear door lock motor**

---


## **C2283**



Double locking



Central locking





---

## **C2285**

---

## **C2285**



---



## **C2288**

---



## **C2288**

Cabriolet

before 95



as of 95





---

## **C2291**

---

## **C2291**



---

## **C3003 - K144 Main beam relay II**

---






**C3003**

as of 95

F04057




---

## C3006 - A70 Instrument cluster

---

## **C3006** (White)

as of 95 1/2



(4) 19 (BN/YE) + 31B-11 (BN/GN)  
19 (BN/YE)


---

## **C3007 - A70 Instrument cluster**

---

## **C3007** (Blue)

as of 95 1/2



---


### **C3008 - N56 Front fog lamp switch**

---

## **C3008** (Violet)

as of 95 1/2

F08060



---


## **C3009 - R2 Cigar lighter**

---

## **C3009**

as of 95 1/2

F03015




## C3010 - N91 Windscreen heater switch

---

### **C3010** (Green)

as of 95 1/2



---


## C3011 - N10 Rear window heater switch

---

**C3011** (Blue)

as of 95 1/2

F08060





---

**C3012**

---

**C3012**

as of 95 1/2





---

**C3013**

---

## **C3013**

as of 95 1/2





---

## **C3014 - A26 Sunroof unit**

---

## **C3014**





---

## **C3015**

---

## C3015

as of 95 1/2



---

## C3016 - K145 Main beam relay I


---



## C3016

as of 95

F04057



---





## C3017

---



## C3017

as of 95



---

## C3018 - N22 Tailgate/decklid switch


---

## **C3018**

as of 95


Higher option content

F03005



Lower option content

F02007



(2) 31B-77C (BN/YE)  
31B-77 (BN/YE)

(1) 31-19A (BN)  
31-X (BK) + 31-19 (BN)  
31B-19 (BN/WH)


---

## **C3020 - D20 Data Link Connector (DLC)**

---

## **C3020**

as of 95 1/2



- (3) 31B-40 (BN/GN) ●  
9-71 (BU/YE) ●  
9-20 (BU/GN) ●
- (4) 31-49B (BN) ●  
31-49R (BN) ●
- (7) 9-64 (BU/YE) ●  
31-20X (BN) ●  
9-64A (BU/YE) ●  
31-D (BK) ●  
31-10D (BN) ●
- (11) 9-20 (BU/GN) ●  
9-72 (BU/GN) ●


---

### **C3021 - K82 HEGO relay**

---

## **C3021**

ZETEC as of 95 1/2  
'96 EEC' emissions  
standard



---


## **C3022 - A74 Diesel pump unit**

---

## **C3022**

as of 95 1/2

F08008




## C3023 - K43 LH Anti-theft flasher relay

---

### **C3023**

as of 95 1/2

F04010




---

## C3024 - K44 RH Anti-theft flasher relay

---

## **C3024**

as of 95 1/2





---

## **C3028**

---

### **C3028** (Yellow)

as of 95 1/2



---


## **C3029 - A117 Seat belt tensioner, driver seat**

---

## **C3029**

as of 95 1/2

F03035



---


### **C3030 - A116 Seat belt tensioner, passenger seat**

---

## **C3030**

as of 95 1/2

F03035



**C3033 - N260 Power window switch, centre console**


---



---

**C3035 - N180 Power window switch, passenger side rear (centre console)**

---



---

**C3036 - N179 Power window switch, driver side rear (centre console)**


---



## **C3036** (Black)

Cabriolet before 95

F07016



---


**C3037 - N183 Power window switch, passenger side rear**

---

## **C3037**


Cabriolet before 95

F07016



Cabriolet as of 95

F07016



---


## **C3038 - N184 Power window switch, driver side rear**

---

## **C3038**

Cabriolet before 95

F07016




(3) 36-3 (BU/WH)  
38-3 (BU/YE)

(6) 35-3 (GN/BK)  
37-3 (GN/WH)

Cabriolet as of 95

F07016



---


**C3901a - P91 Central junction box (CJB)**

---

LHD

as of 95, except RS  
Cosworth

F10002




### C3901a

(Natural)

RHD

as of 95, except RS  
Cosworth

F10002




## C3901b - P91 Central junction box (CJB)

LHD

as of 95, except RS  
Cosworth

F10002.01




### C3901b

RHD

as of 95, except RS  
Cosworth


F10002.01



## C3901c - P91 Central junction box (CJB)

LHD


as of 95, except RS  
Cosworth  
F04029



### C3901c

RHD


as of 95, except RS  
Cosworth  
F04029



## C3901d - P91 Central junction box (CJB)

LHD


as of 95, except RS  
Cosworth  
F04024



### C3901d

RHD

as of 95, except RS  
Cosworth  
F04024




## C3901e - P91 Central junction box (CJB)

## C3901e

LHD

as of 95, except RS  
Cosworth


F04025



RHD

as of 95, except RS  
Cosworth


F04025



## C3902a - P91 Central junction box (CJB)

LHD


as of 95, except RS  
Cosworth  
F10002.01




## C3902a

RHD

as of 95, except RS  
Cosworth  
F10002.01




## C3902b - P91 Central junction box (CJB)



## C3902c - P91 Central junction box (CJB)

### C3902c




## C3903a - P91 Central junction box (CJB)



## **C3903a**

as of 95, except RS  
Cosworth

F10002.01



(1) 15-12A (BK/GN)  
XL-2 (PK)

(2) 31B-88 (BN/WH) + 31B-88B (BN/WH)  
31B-88A (BN/WH)  
31B-88 (BN/WH) + 31B-88A (BN/WH)

---


### **C3903b - P91 Central junction box (CJB)**

---



## **C3903b** (Natural)

as of 95



(1) 58-5 (GY/BK) **LHD**  
58-4 (GY/RD)

(2) 58-4 (GY/RD) **LHD**  
58-5 (GY/BK)

---


**C3903c - P91 Central junction box (CJB)**

---

## **C3903c**

as of 95

F04029



(3) 31-28Z (BN)  
31-28Z (BN) +XL-3 (PK)  
XL-3 (PK)

(1) 31-1 (BN) +31-28Z (BN)  
31-1 (BN)

---


## **C3903d - P91 Central junction box (CJB)**

---

## **C3903d**

as of 95


F04025





(1) 61 (BU) +61-A (BU)  
61 (BU)

---

# C3903e - P91 Central junction box (CJB)



# C3904 - P91 Central junction box (CJB)




# C3905a - P91 Central junction box (CJB)

## **C3905a**

as of 95, except RS  
Cosworth

F07020



(1) 58-3A (GY/BK) +58-9J (GY/YE)  
58-3A (GY/BK)


---

**C3905b - P91 Central junction box (CJB)**

---

## **C3905b**

as of 95, except RS  
Cosworth



---


### **C3905c - P91 Central junction box (CJB)**

---

## **C3905c**

as of 95, except RS  
Cosworth

F07020



(1) 31B-87 (BN/BK)  
31-17 (BN)

(2) 31-15 (BN) ●  
54-15 (BK/RD) ●


---

**C3905d - P91 Central junction box (CJB)**

---

## C3905d

as of 95, except RS  
Cosworth




---

## C3908 - P91 Central junction box (CJB)

---

### C3908

as of 95, except RS  
Cosworth




---

## C3909a - P91 Central junction box (CJB)

---

## **C3909a**

as of 95, except RS  
Cosworth



---


### **C3909b - P91 Central junction box (CJB)**

---



## **C3909b**

as of 95, except RS  
Cosworth



(3) 31-21 (BN)  
31-65 (BN)  
31-32 (BN) +31-65 (BN)

(1) 54-13 (BK/YE) ●  
54-13 (BK/YE) +54-39 (BK/BU) ●

(4) 30-37A (RD) +30-37B (RD) ●  
30-37 (RD) ●

(2) 30-22 (RD/YE) ●  
30-22 (RD/YE) +30-22A (RD/YE) ●  
30-22E (RD/YE)

---


**C3910 - P91 Central junction box (CJB)**

---

## **C3910**

as of 95, except RS  
Cosworth

F07020



---


**C3911 - P91 Central junction box (CJB)**

---

## **C3911**

as of 95, except RS  
Cosworth

F07020




---

### **C3912 - P91 Central junction box (CJB)**

---

## **C3912**

as of 95, except RS  
Cosworth  
F04085




---

## **C9000 - N97 Front seat adjust switch**

---

## **C9000**

F07016




C9311

C9311

Van  
Fuel injection




Van  
Diesel



C9649 - Y31 A/C Clutch solenoid


C9649



C9905 - A15 EEC IV module

**C9905** RS Cosworth

FB0004



(1) 30-4 (RD) 30-4T (RD)	(21) 31B-73A (BN/YE)	(41) 31-1C (BN) ●
(2)	(22) 31-70A (BN) 31-55 (BN)	(42) 31B-9C (BN/WH) ●
(3) 31B-20 (BN/RD) 31B-82D (BN/RD)	(23)	(43)
(4) 15-V (BK) 15-U (BK)	(24) 31B-61 (BN/RD)	(44) 31B-1B (BN/WH)
(5) 31-1G (BN) ●	(25) 31B-85D (BN/YE)	(45) 31B-11G (BN/GN)
(6)	(26) 54-32D (BK/YE)	(46) 31-1A (BN) 31-1B (BN)
(7) 31B-75A (BN/GN)	(27) 31B-18B (BN/BK) ●	(47) 31B-13C (BN/GN)
(8)	(28) 31B-62 (BN/YE) ●	(48) 9-68 (BU/WH)
(9) 31B-12B (BN/YE)	(29) 9-66 (BU/RD) ●	(49) 9-64A (BU/YE) ●
(10) 54-16E (BK/WH)	(30)	(50) 31B-12A (BN/YE)
(11) 31B-10B (BN/WH)	(31) 31B-9G (BN/WH) ●	(51) 31B-9 (BN/WH) ●
(12) 31B-35 (BN/GN) ●	(32)	(52) 31B-9E (BN/WH) ●
(13) 31B-68A (BN/YE)	(33) 31B-9B (BN/WH) ●	(53) 31-70 (BN) ●
(14)	(34)	(54) 31B-35 (BN/GN) 31B-9D (BN/WH)
(15) 31B-9G (BN/WH) ●	(35) 31B-9D (BN/WH) ●	(55) 31-1A (BN) ●
(16) 31-19B (BN)	(36) 15-12A (BK/GN)	(56) 15-3B (BK/BN)
(17) 9-69 (BU/RD)	(37) 54-15D (BK/RD)	(57) 54-15E (BK/RD)
(18) 9-65 (BU/GN)	(38) 31-1F (BN) ●	(58) 31B-9 (BN/WH) 15-K (BK)
(19) 9-64 (BU/YE)	(39) 31B-9C (BN/WH) 31-55A (BN)	(59) 31B-9E (BN/WH) ●
(20) 31-81B (BN)	(40) 31-9M (BN)	(60) 31-19A (BN)